



RCMT

Manual On/Off Remote Control with Timer INSTALLATION AND OPERATING INSTRUCTIONS

This basic on/off remote control system provides a safe, reliable, and user-friendly remote control for milli-volt valve gas appliances. The system can be manually turned on and off with the transmitter. Always check with the home owner's manual of the appliance for additional information, warnings regarding accessory installation before connecting this remote control system.

Carefully inspect the contents for shipping damage. If any parts are missing or damaged, immediately contact the dealer from whom you purchased the kit. Do not attempt to install any part of the kit unless all parts are in good condition. Please keep this manual for future reference.

CONTENTS OF KIT

Description	Qty
Transmitter	1
Battery Alkaline AAA (for Transmitter)	3
Battery Alkaline AA (for receiver)	4
Receiver (Assembly) consists of :	1
Receiver Box	
Slide Button-Black (On/RS/Off)	
Wall Cover Plate-Black	1
Wall Cover Plate-White	1
Slide Button-White (On/RS/Off)	1
Battery Door-White	1
Plug-In Wiring Assembly – 22" Inches	1
Velcro (Loop and Hook)	1
Installation Instructions	1
#6 3/4" Screws, Zinc	2
#8 Screws (for fireplace system control covers)	2

FEATURES/SPECIFICATIONS

- Battery Powered Transmitter and Receiver
- Easy Access Front Battery Door
- Pre-Programmed for Quick Installation
- 16 Security Codes
- Quick Disconnect Wiring Assembly
- Optional 6 hour shutdown timer on receiver
- Low battery indicators for Transmitter and Receiver

WARNING

Important Safety Information

- Read this manual thoroughly prior to installing, programming or operating any remote control.
- This remote control system is designed for use with a milli-volt or 24V gas valve system. Do not use this remote control system on applications with voltages above 30 Volts AC.
- This remote control system requires three (3) "AAA" and four (4) "AA" alkaline batteries to power the transmitter and receiver. Wiring must conform to appliance requirement and building codes/ordinances as required by local and national code authorities having jurisdiction.
- Do not short (or jumper) across the gas valve terminals to test the remote control installation. This could damage the unit and void the warranty.
- This remote control system should only be used as described in this manual. Any other use is not recommended and will void the warranty.

WARNING

Turn appliance OFF and allow to cool before installing or servicing. **DO NOT** connect 110-120 VAC wiring to the milli-volt gas control valve. The remote operator must be installed exactly as outlined in these instructions. Read all instructions completely before attempting installation. Follow instructions carefully during installation. Any modification of components will void the warranty and may cause a fire hazard.

WARNING

Turn appliance OFF (at the appliance or remote receiver) if you are away from your house for a long period of time.

INSTALLATIONS



Remote Receiver

The remote receiver may be wall mounted or installed in the appliance per the appliance homeowner's manual. **Refer to the Homeowner's Manual for special installation instructions.** If wall mounted, the remote receiver must be installed in a junction box with cover plate provided. Failure to follow the installation instructions found in the appropriate Homeowner's Manual will void the warranty and may cause a fire hazard.

Installing Batteries

The remote receiver uses four (4) "AA" batteries. To install batteries,


1. Open the battery door by pressing the two tabs located on the door.
2. Install the batteries as indicated in the receiver.
3. Close the battery door until the door tab snaps in place.
4. To install the receiver into a wall junction box, snap wall cover plate to the receiver and install the receiver with the screws provided to the junction box.
5. Gently, install the slide switch back to the receiver stem.



6. The batteries should be replaced at least once every 6 months or when the battery indicator flashes.

Installing Wire

This system comes with a 22 inch pre-assembled wire assembly. Insert the white terminal to the back of the receiver. The terminal wire block can only be installed one way. Do not force the terminal plug onto the receiver. Follow the homeowner's manual for connecting the two (2) 1/4" female spade terminals to the milli-volt valve. Connect to the two (2) 1/4" female spade wiring terminals.



WARNING


Make sure that the wires do not contact the appliances any place other than at the terminals. Exposure to temperatures higher than 105C (250°F) may cause the receiver to malfunction or fire hazard.

Remote Transmitter

Installing Batteries

The remote transmitter uses three (3) "AAA" batteries. To install batteries,

1. Press down the battery door tab and lift up and remove the battery door.
2. Install the batteries as indicated on the transmitter cover.
3. Close the battery door by snapping in place.
4. The batteries should be replaced at least once every 6 months or when the battery indicator flashes.




Back of the Transmitter

Setting Privacy (DIP) Switch on Receiver and Transmitter

The remote receiver and transmitter privacy (DIP) switches are preset at the factory. In the event of activation or interference from other nearby transmissions, reset the code using the following procedure:

1. Slide the code switches on the transmitter or receiver to your choice of ON or OFF position. Switches #1, #2, #3 and #4 are preset to "ON" for both the transmitter and receiver.
2. The switches on the transmitter and receiver must match in order for the system to work.
3. The system is now ready to operate.
4. See optional 6 hour shutdown on receiver section.



WARNING

Do not use two (2) or more remote control systems in the same area with the same dip switch settings, as they will communicate with each other. This may cause the appliances to malfunction.

OPERATIONS:

Transmitter



General

The RCST Remote Control provides the manual and timed fireplace on/off operation.

The transmitter will operate the remote receiver from 1foot to a maximum of 30 feet. The distance is reduced when batteries are low or when the receiver is inside a metal enclosure.

Initial Start-up

1. After initial power up or when RESET button is pressed, the transmitter is reset. The reset button is located inside the battery door.
2. During system reset, all features of the LCD display will be visible. After one second, the LCD displays will be initialized. A typical reset display is shown above. Note that the temperature scale is degree F.
3. Press the **ON** button to select between °C and °F display. It will exit setting mode automatically after 10 seconds if no key is pressed. The transmitter will send an off signal after reset.
4. After reset the transmitter is operating in manual mode. The room temperature is shown as above.




Manual Mode

1. Press the **ON** button once to turn on the appliance. Press the **OFF** button to turn it off.


Timer Mode

1. Press the **TIMER** button once to start the timer, 90 min as shown in the left Figure. Keep pressing the **TIMER** button to set up timer to 60 or 30 min as desired. Three seconds later, the transmitter will turn on the fireplace.
2. Once the timer starts to count down to 0 min, the transmitter will send off signal and turn off the fireplace.
3. Press the **OFF** button to exit the timer mode and the transmitter will shut off the fireplace.




Low Battery Detection

1. When the battery voltage drops to a certain level, the LED on the transmitter will blink until the battery expires. Change the battery before the battery is too weak for normal operation. **TURN THE UNIT OFF BEFORE REPLACING BATTERIES.**




Child-Proof Protection

1. Press and hold the **ON** button and the **OFF** button simultaneously for 3 seconds to enter child-proof mode.
2. The transmitter will not work until child-proof mode is deactivated by pressing the **ON** button and the **OFF** button simultaneously for 3 seconds again to exit child-proof mode.



Transmitter Thermal Shutdown

1. If transmitter measures a room temperature exceeding 99 degrees Fahrenheit, the LCD will display "HI" and the transmitter will turn off the appliance.
2. Transmitter will not function until the room temperature has dropped below 99 degree Fahrenheit.
3. If transmitter measures a room temperature less than 40 degrees Fahrenheit, the LCD will display "LO" and **NO SIGNAL will be sent to turn on the appliance.**



Receiver

Low Battery Detection

When the battery voltage drops to a certain level, which is checked once a minute, the low-battery LED will start to blink and the receiver **will automatically turn off the appliance.** The receiver will not function again until fresh batteries are installed.

Optional 6 Hour Shutdown

1. The receiver comes preset from the factory with a 6 hour shutdown from its last ON operation. This is done to prevent the appliance from continuing to run if unattended.
2. You may disable this feature if you wish. To disable, change the receiver privacy (DIP) switch #1 ONLY to the OFF position. Make sure the transmitter privacy (DIP) switches are set the same. Follow the instructions on Setting Privacy (DIP) Switch on Receiver & Transmitter discussed earlier in this manual.
3. **By disabling this feature, your appliance may continue to run unattended.**

Slide Switch

1. ON position: the system will remain on until the slide switch is placed in the OFF or RS position.
2. RS position: the system will only operate if the remote receiver detects a signal from the transmitter.
3. OFF position: the system is off. The slide switch should be placed in the OFF position if you will be away for an extended period of time. If the remote receiver is mounted out of children's reach, the OFF position also functions as a safety device by both turning the system off and rendering the receiver inoperable.

TESTING YOUR NEW REMOTE CONTROL SYSTEM

1. Connect the wiring terminal to the appliance. Refer to the appropriate Homeowner's Manual for proper wiring connections.
2. Light your gas appliance following the lighting instructions that came with the appliance. Confirm that the pilot light is on; it must be in operation for the remote control to operate the main gas valve. Appliance pilot control knob must be in the ON position. Appliance ON/OFF switch must be in OFF position.
3. Slide the 3 position button on the remote receiver to the ON position. The main gas flame should ignite.
4. Slide the button to OFF. The flame should extinguish (the pilot light will remain on).
5. Slide the button to RS (the center position), then press the **ON** button on the transmitter to turn the system to ON. The main gas flame should ignite.
6. Press the **OFF** button on the transmitter to turn the system off. The flame should extinguish (the pilot light will remain on).

TROUBLESHOOTING

Symptom	Causes	Action
1. LED light on the receiver blinking	1. Low Battery	1. Replace batteries. Change batteries every 6 months. 2. Check battery installation and replace batteries.
2. Appliance does not come on after pressing the ON button in transmitter	1. Wiring / Electrical Connections	1. Slide the switch to ON, if appliance comes ON, wiring is not the cause. 2. If appliance does not come on, check wiring connections.
	2. Privacy (DIP) switch setting on transmitter does not match receiver	1. Make sure the transmitter and receiver have the same DIP switch settings.
	3. Distance between the transmitter and receiver is more than 30 feet	1. Make sure the operating distance is less than 30 feet
3. Receiver cannot detect signal.	1. Receiver is installed in an enclosure.	1. Make sure the receiver is not located inside to tight of an enclosure.

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

WARRANTY

This warranty gives you specific legal rights and you may also have other rights that vary from state to state or province to province. Answers to any questions regarding our limited warranty may be obtained by writing our corporate offices.

Ambient Technologies warrants each new Ambient Technologies remote control against any defects that are due to faulty material or workmanship to the original owner, for a period of five years after the original date of purchase. This warranty and our liability does not apply to batteries, nor does it include damage to merchandise or the remote control resulting from accident, alteration, neglect, misuse, improper installation or any other failure to follow Ambient Technologies installation and operating instructions.

Ambient Technologies agrees to repair or replace at its option any Ambient Technologies remote control under warranty provided it is returned postage prepaid to our warranty facility in a padded carton within the warranty period, with proof of the original date of purchase and a brief description of the malfunction. This limited warranty does not include the cost of removal or re-installation. **All Ambient returns must have a return authorization number from Ambient Technical Support.**

Ambient Technologies
149 Cleveland Drive
Paris KY 40361

**FOR TECHNICAL SUPPORT
CALL 800-398-6195**