




Intelligent Design™

# Assembly Instructions

## Model: CDG48

- \_\_\_ (1) Seat
- \_\_\_ (1) Back
- \_\_\_ (2) Sideframes
- \_\_\_ (2) Glider Base Frames
- \_\_\_ (2) Glider Cross Brace
- \_\_\_ (1) Hardware pack

### TOOLS NEEDED




4MM T-HANDLE HEX KEY  
(INCLUDED)

**\*NOTE:** ALL FINE THREAD BOLTS (A) AND (B), WILL THREAD INTO EITHER THE TUBE OR AN INSERT NUT. COURSE THREAD SCREWS GO STRAIGHT INTO THE POLY


#### Step 1

Attach sideframes to seat using (4) 1½" chair bolts (A).  
**DO NOT TIGHTEN!!**



#### Step 2

- Attach back to sideframes using (2) 2¼" chair bolts (B) into the tube on top and (4) 2½" screws (C) on bottom
- Attach center of the back to the seat using (1) 2½" screw (C)




#### Step 3

-Tighten the 1½" chair bolts from Step 1

-Attach cross braces to the glider base frames with (4) 2½" screws (C)

#### Step 4

-Attach glider base to bench with (4) 1½" chair bolts (A).



Qty. Description

8	A - 1/4-20 X 1-1/2 WAFER SHCS FINE THREAD
2	B - 1/4-20 X 2-1/4 WAFER SHCS FINE THREAD
9	C - .27 X 2 1/2 SOCKET WAFER "A"