



Intelligent Design™

Model: ECD24


- (1) Seat
- (1) Back
- (2) Front legs
- (2) Back legs
- (2) Arms
- (1) Footrest
- (1) Short brace
- (2) Side brace
- (2) Braces
- (1) Hardware pack

TOOLS NEEDED




7/16 Wrench
4mm HEX KEY, ALLEN, T-HANDLE
(INCLUDED)

Step 1
Lay seat on its side.
Attach front leg and back leg
to seat. Now flip seat around and
do the other side. Uses (8) 1-7/8" bolts,
nuts and washer




Step 3
Attach back to seat
using (2) .27x2" screws


Attach back to rear leg
using (2) .27x3" screws



Step 2
Attach arms to front leg using
(2) 2-1/4" bolts, nuts and washer
Attach braces to legs using
(4) .27x2" wafer screws



Step 4
Attach footrest to side braces
using (2) .27x2" screws
Attach sidebrace to front legs
using (2) 2-1/4" bolts, nuts, washer
Attach short brace to sidebrace
using (2) .27x3" screws



Qty. Description

- 8 A-.27 X 2 SOCKET WAFER A
- 4 B-.27 X 3 SOCKET WAFER A
- 8 C-1/4-20 X 1-7/8 WAFER SHCS
- 4 D-1/4-20 X 2-1/4 WAFER SHCS
- 12 E-1/4 FLAT WASHER
- 12 F-1/4-20 NYLOCK NUT