



Intelligent Design™

Model: SBD30

- (1) Seat
- (1) Back
- (2) Front legs
- (2) Back legs
- (2) Arms
- (1) Footrest
- (1) Short brace
- (2) Side brace
- (4) Braces
- (1) Hardware pack


TOOLS NEEDED



7/16 Wrench
4mm HEX KEY, ALLEN, T-HANDLE
(INCLUDED)

Step 1


Lay seat on its side.
Attach front leg and back leg
to seat. Now flip seat around and
do the other side. Uses (8) 1-7/8" bolts,
nuts and washer



Step 3


Attach back to seat
using (2) .27x2" screws

Attach back to rear leg
using (2) .27x3" screws




Step 2

Attach arms to front leg using
(2) 2-1/4" bolts, nuts and washer
Attach braces to legs using
(8) .27x2" screws



Step 4

Attach footrest to side braces
using (2) .27x2" screws
Attach sidebrace to front legs
using (4) 2-1/4" bolt, nut and
washer
Attach short brace to sidebrace
using (2) .27x3" screws



Qty.	Description
12	A-.27 X 2 SOCKET WAFER A
4	B-.27 X 3 SOCKET WAFER A
8	C-1/4-20 X 1-7/8 WAFER SHCS
6	D-1/4-20 X 2-1/4 WAFER SHCS
14	E-1/4 FLAT WASHER
14	F-1/4-20 NYLOCK NUT